

- 1.**
Stretch the waterstop over the pipe



- 2.**
Place the Rubber collar over the rubber band on the waterstop



- 3.**
Place the stainless steel band over the collar and tighten the clamp.

